

EXCELLENCE

TECHNICAL SPECIFICATIONS

- Valve type : 1/2" ceramic disc valve 3/4 turn tested to 500,000 cycles.

- PRESSURE

Minimum working pressure	0,2 bar
Recommended working pressure	1 - 5 bar
Maximum working pressure	10 bar
Test pressure	16 bar

WHERE INLET PRESSURE EXCEEDS
5 bar FIT PRESSURE REDUCING VALVE


These valves are designed to work on balanced pressure supplies and are suitable for use with tank feed supplies, combination Boiler/Multipoint supplies or supplies from direct mains feed systems.

Subject to minimum/maximum pressure requirements as above

- TEMPERATURE




Minimum working temperature	1°C
Maximum (at hot water inlet)	85°C
Recommended temperature range	5°C - 60°C

- FLOW RATE



IF THE PRESSURE IS HIGHER THAN 1 bar
REMOVE FLOW STRAIGHTENER AND REPLACE
WITH AERATOR PROVIDED

To exchange aerator/ flow straightener unscrew the housing (31.1) from the spout, change the innerpart (flow straightener)(31.2) by the aerator supplied and re-assemble ensuring that washer (31.3) is in the correct position.



Congratulations on your purchase of a CIFIAL product.

To ensure that this product gives you satisfaction over many years, please follow the simple instructions detailed here

INSTALLATION INSTRUCTIONS

1. Ensure that supply requirements with regard to pressure and temperature are complied with. (See technical specifications)
2. Remove 1/2" backnut (1) at base of tee assembly on the spout. Remove lower brass washer (2), tee assembly (4) and upper brass washer (6) from base of spout. Remove 3/4" backnut (7) and dished washer (8). Locate spout into hole in basin, ensuring that base plate (10) and rubber washer (9 and 11) are correctly located. Re-fit dished washer and backnut and tighten securely. Re-assemble tee assembly in reverse order ensuring that O-rings (3) and (5) are properly located on tee. Tighten backnut (1) fully, ensuring that inlet connections of tee as facing along basin towards valves.
3. Loosen backnuts (13) on valve bodies and fit dished washer (14) (raised edge of dished washer to face upward towards basin) Feed valve bodies through basin from underside. Fit O-ring (16) and screw locknut (17) to valve bodies from above the basin and tighten securely. Tighten backnuts (13) compressing dished washer (14) to underside of basin ensuring that outlet connections (21) face towards tee on spout. Connect flexible hoses between valve outlets (21) and inlet connections on tee assembly (4) once again ensuring correct seating of washers (See position of hoses in the cover drawing of these instructions.)
4. Fit decorative bases (19) on the locknut (17), fixed by O-ring (18). Fit spindle extensions (20) to spindles on valves. Remove decorative insert from handwheel, locate handwheel to spindle extension and tighten screw. Re-fit decorative insert.
5. Fit top half of pop up waste section (22) through basin, fitted with cone shaped sealing washer supplied (23), or sealed with silicone if appropriate. Seat round rubber washer (24) to bottom half of pop up waste section (25) and screw firmly to top half (now projecting through basin waste hole), ensuring on completion that the connection for horizontal pop up rod is facing directly below tee assembly (4).
6. Fit ball end of horizontal pop up rod (27) into connection point on bottom section of pop up waste fitting with seal (28) provided and tighten capnut (26) by hand as tight as possible. Fit link piece (29) to vertical and horizontal pop up rods and tighten screws to both rods. Adjust pop up plug screw section (30) to required length, ensuring that the plug seats properly into waste fitting when plug is down but that plug lifts clear of waste when pop up knob (12) on spout is depressed, then tighten locking nut firmly. If plug reseats itself into waste when pop up knob on the spout is released, tighten capnut (26) on bottom section of waste fitting further.

YOUR MIXER IS NOW READY FOR PLUMBING CONNECTIONS

7. Fit 1/2" FBSP tap connectors (Not Supplied) to ends of copper tube, then to male ends of valve tails with fibre, rubber or PTFE washers.
8. Fit 1.1/4" waste trap to bottom section of waste assembly and to waste discharge pipe.
9. Remove aerator or straightener (31) before opening isolation valves to test supplies and flush pipework. Check both supply and waste connections for leakage and flush through thoroughly to remove any sediment from the system. Refit aerator or flow straightener.

MAINTENANCE INSTRUCTIONS

1. Cleaning:

Clean the product with warm soapy water and a soft cloth. Light deposits of scale can be removed by washing with a diluted solution of vinegar and water in equal parts. Rinse with tepid clean water and dry with a soft cloth.

Never use acid or abrasive cleaning materials.

Periodically the aerator in the mixer spout should be cleaned to remove deposits of scale. Unscrew the aerator (31) from the spout and dismantle. Open the cold tap and rinse the pieces of the aerator under the running water, using a soft brush if necessary then re-assemble and re-fit the aerator.

Do not clean any plastic pieces with products containing alcohol, acetone or any disinfectants.

2. Valve Maintenance:

Turn off hot and cold water supply. Check it is off by opening the mixer.

To access the valve body, pull up and off the decorative piece of the tap handwheel, remove the now exposed screw thereby enabling removal of the insert and main section of the handwheel. Pull up and off the decorative base (19). Unscrew the large hexagon section of the valve body (15) from the tap body. Flush through thoroughly and re-fit **do not** disassemble. Re-fit ensuring the extension (20) is correctly located. For further information contact Cifial (UK).

3. Finish Protection:

If the mixer is fitted in an area not frequently used, ensure that evaporation does not cause the water level in the trap to diminish as the fumes from the drain can be harmful to plated finishes, simply run the tap once a week for a few seconds.